

Important Notes

- Installation of this urinal must be in accordance with Australian Standard AS/NZS 3500.2. Prior to installing a waterless urinal to an existing system, the installer shall determine the materials of the pipes in the existing system. The undiluted discharge from a waterless urinal shall not be transported through copper or copper alloy pipework.
- Ensure pipe work is free from blockages and obstructions

Installation Instructions

- ① Mark holes for mounting brackets with reference to the diagram
- ② Attach the mounting brackets with correct fixings for wall type
- ③ Ensure Wall Outlet Pipe protrudes 50mm from wall
- ④ **Lubricate the rubber** outlet seal on Urinal Drain Outlet to ensure it slides onto the PVC Wall Outlet Pipe
- ⑤ Hang urinal on mounting brackets allowing Urinal Drain Outlet to line up with Wall Outlet Pipe
- ⑥ Push urinal firmly so Rubber Outlet Seal slides onto Wall Outlet Pipe
- ⑦ Flush drain line with water to ensure there are no leaks
- ⑧ Apply silicone or similar around outer edge of urinal
- ⑨ Insert Desert No Flush cartridge into urinal
- ⑩ Pour 500mL of water through the urinal to create water seal in cartridge.
- ⑪ Place 1 Desert cube in cube holder and place stainless steel lid on top

Parts

- Urinal Bowl
- Mounting Brackets
- Mounting Screws
- Desert No Flush Cartridge
- Stainless Steel Lid



WaterMark

WMTS-459

Certificate No. 23054

