

DESERT NO FLUSH CARTRIDGE CLEANING

INSTRUCTIONS

Daily Cleaning Procedure:

1. Rinse the urinal with 1L of cold water.
2. Remove any hair and debris from the urinal.
3. Wipe down urinal surface with damp microfibre cloth. Pay attention to underside of urinal and tiles below.
4. Lift up stainless steel cover and clean both sides.
5. Check Desert Cube. Replace when cube has dissolved to the size of a 5c piece.

Replacing Cartridge:

Spare cartridges are provided in the case of a blocked urinal. These cartridges can be swapped out to resolve the blockage. To replace a cartridge;

1. Remove stainless steel top and Desert Cube. Place to the side.
2. Hold the round top plastic section of the cartridge and slowly pull straight up whilst rotating the cartridge 90 degrees. DO NOT PULL ON AN ANGLE OR CARTRIDGE MAY FALL APART.
3. Turn the blocked cartridge upside down to drain of all liquid.
4. Hold new cartridge by round top plastic section and gently push straight down into drain. ENSURE TOP FIN OF RUBBER BUNG IS BELOW TOP OF DRAIN.
5. Pour 500mL of water through cartridge.
6. Replace Desert Cube and Stainless Steel top.
7. DO NOT THROW DIRTY CARTRIDGE AWAY. PLACE IN RESEALABLE BAG PROVIDED AND DESERT WILL COLLECT AT NEXT SERVICE.

IMPORTANT:

PLEASE ENSURE EVERY CARTRIDGE HAS A RUBBER BUNG TO HOLD THE PLASTIC CARTRIDGE IN PLACE AND THE MSB (LONG CYLINDER) IS CLIPPED ON. IF NOT, THE CUSTOMER WILL EXPERIENCE STRONG ODOURS.

Rubber Bung ----->

MSB (long Cylinder) ----->

